


2000S Ergo Flex



ART. NO. DESCRIPTION

1. 970016	Starlock washer 8mm	15. 970009	One wave washer M8
2. 80251	Lower gas spring fastener M10	16. 997909	Bolt M8x60
3. 970032	Gas spring	17. 999370	Friction washer 50mm
4. 70194	Upper gas spring fastener	18. 80022	Front arm; long
5. 70196	Stainless steel rivet	19. 80083	Extension 110 mm
6. 70097	Pin 4x20	20. 999367	Lock nut M8
7. Contact	Lower seat adapter	21. 999368	Belleville washer M8
8. Contact	Upper seat adapter	22. 80688	Steel T
9. 70354	Friction washer 70mm	23. 993104	Carriage bolt M8x25
10. 970033	Carriage bolt M10x30	24. 80073	L-shaped plate
11. 999379	One wave washer M10	25. 993025	Bolt M8x20
12. 999380	Lock nut M10	26. 999369	Set screw M8x10
13. 80023	Back arm right	27. 80133	Rail holder
80024	Back arm left	28. 80591	Pad E incl. rail right
14. 970030	Hand screw M8x15	80939	Pad E incl. rail left